

Questions or Concerns Contact Canarm At:
1-800-265-1833 (English) or 1-800-567-2513 (French)
Monday Through Friday 8:00am - 5:00pm E.S.T.

REQUIRED: Wrench
Pliers
Phillips Screwdriver
Wire Cutters

Wiring supplies
as required by
electrical code

SAFETY PRECAUTIONS:







1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.

DO NOT REMOVE INSULATION FROM FIXTURE.

2. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

NOTE: Product May Not Look Exactly As Shown In Figures.

INSTALLATION:



1. Attach the mounting bracket to the outlet box using electrical box screws and flat washers. Attach the nipple to the mounting bracket and adjust until it will clear the canopy when assembled (Place the canopy over the nipple and tighten the upper connector onto the nipple until snug. The upper connector should hold the canopy snug to the ceiling). Lock the nipple in the correct position using the brass nut.

2. Spread one end of chain open and fasten to the lower connector. Weave the power cord and ground wire through the links in the chain. Spread the other end of the cord open and fasten to the upper connector.

3. Feed the wires through the hole in the upper connector. Loosen off the nut on the upper connector and slide it down the chain towards the lower connector. Slide the canopy down the chain towards the lower connector.

4. Feed the wires through the nipple and tighten the upper connector onto the nipple.

5. Connect the copper wire to ground screw in electrical box. Connect the black wire (or wire marked "SPT-1") from the fixture to the black wire in the electrical box and connect the white wire from the fixture to the white wire in the electrical box.







6. Tuck electrical wires into electrical box. Slide canopy into position and tighten in place by sliding upper connector nut into position and tighten.

Note: If required, hook the support arms onto fixture and then into the glass (or hoop).

Note: If required assemble centre body of fixture.

Note: If your product does not have any uplights, please proceed to Step 8.

Note: If required, spread the arms of the fixture out evenly.



7. Note: Refer to the style of assembly that matches the style of your fixture.
If your fixture has shades,

STYLE #1A - Place shade on tube, then install bulb.

STYLE #1B - Install bulb, shade then finial.

STYLE #2 - Remove spinner nut from socket. Position glass on lamp and secure with spinner nut.
Note: Glass may face up or down.

Note: If your fixture has candle-style lights, slide the tubes over the upright sockets

STYLE #3 - Install proper bulb type and wattage before assembling the glass. Remove ball screw from the curved stem. Position glass on lamp with the curved stem being inserted through the hole in the glass. Hand tighten the ball screw to secure the glass in place.

8. If not already done, install proper bulb type and wattage.
Note: If your product does not have a bottom light, your fixture is complete.

9. Attach the stem to the fixture.

10. Position the glass over the stem. Secure the glass in place using the fibre washer, hex nut, decorative cap and finial.